Introduction to Pioneer 3-DX, ARIA and MobileSim

What is Pioneer

 Pioneer is a family of mobile robots, including two-wheel and four-wheel drive versions.

http://www.mobilerobots.com/








Pioneer 3-DX




Pioneer LX

Pioneer 3-DX

Specifications





Side view


Top view

Control Panels

Pioneer 3-DX


- Sonars
 - 8 sonar arrays: One on each side, and six facing outward at 200 intervals
 - O Range from 10cm to 5m

Sonar numbers



Connection Options

 All MobileRobots platforms are served in a client-server architecture.



ARIA


- Open-source C++ library for all MobileRobots platforms and many accessory devices.
- Applications developed with ARIA can easily navigate the mobile platform, as well as manage odometry, sensor readings, and other operating data.
- Download link: https://reurl.cc/W4dl2x
- Recommended OS: Ubuntu 16.04

Examples of ARIA

- Path
 - /usr/local/Aria/examples
- Important examples
 - o demo.cpp
 - General purpose testing and demo program, using ArMode classes to provide keyboard control of various robot functions.
 - wander.cpp
 - Example using actions and sonars to implement a random wander avoiding obstacles.

MobileSim

- MobileSim provides a simulation environment for MobileRobots platforms and many accessories.
- Download link: https://reurl.cc/Qpdzr5
- The following pages show how to run MobileSim on and Ubuntu.




ARIA and MobileSim on Ubuntu

- 1. Download ARIA and MobileSim for Ubuntu 16.04
 - ARIA 2.9.4: https://reurl.cc/W4dl2x
 - MobileSim 0.9.8: https://reurl.cc/Qpdzr5
- 2. Install them with the files.
 - They should be located at:
 - /usr/local/Aria
 - /usr/local/MobileSim
- 3. Make ARIA before use it.

Install ARIA and MobileSim

You can install them by clicking the files directly.




Install ARIA and MobileSim

 If you encounter some problems when installing them, you can enter the following command.


```
ubuntu:~/Downloads$ ls
ibaria 2.9.4ubuntu16 amd64.deb mobilesim 0.9.8ubuntu16 amd64.deb
     ubuntu:~/Downloads$ sudo dpkg -i *.deb
Selecting previously unselected package libaria.
(Reading database ... 175155 files and directories currently installed.)
Preparing to unpack libaria 2.9.4ubuntu16 amd64.deb ...
Unpacking libaria (2.9.4+ubuntu16) ...
Selecting previously unselected package mobilesim.
Preparing to unpack mobilesim 0.9.8ubuntu16 amd64.deb ...
Unpacking mobilesim (0.9.8+ubuntu16) ...
Setting up libaria (2.9.4+ubuntu16) ...
ARIA has been installed in /usr/local/Aria.
Header files are in /usr/local/Aria/include. Documentation is in /usr/local/Aria/docs.
libAria.so is in /usr/local/Aria/lib.
Adding /usr/local/Aria/lib to /etc/ld.so.conf...OK.
running ldconfig...
Setting up mobilesim (0.9.8+ubuntu16) ...
MobileSim has been installed in /usr/local/MobileSim.
Processing triggers for gnome-menus (3.13.3-6ubuntu3.1) ...
Processing triggers for desktop-file-utils (0.22-1ubuntu5.1) ...
Processing triggers for bamfdaemon (0.5.3~bzr0+16.04.20160824-0ubuntu1) ...
Rebuilding /usr/share/applications/bamf-2.index...
Processing triggers for mime-support (3.59ubuntu1) ...
Processing triggers for libc-bin (2.23-Oubuntu9) ...
     @ubuntu:~/Downloads$ cd /usr/local/
    @ubuntu:/usr/local$ ls
     bin etc games include lib man MobileSim sbin share src
```

Make sure you have "Aria" and "MobileSim" directories after installing.


Load map



Load map



Load map



Run demo

```
@ubuntu:/usr/local/Aria/examples$ ./demo
Connnecting to robot using TCP connection to localhost:8101...
Connecting to simulator through tcp.
Syncing 0
Syncing 1
Syncing 2
Connected to robot.
Name: MobileSim
Type: Pioneer
Subtype: p3dx-sh-lms1xx
ArConfig: Config version: 2.0
Loaded robot parameters from /usr/local/Aria/params/p3dx-sh-lms1xx.p
Robot Serial Number: SIM
ArRobotConnector: Connected to simulator, not connecting to additional hardware
components.
lms1xx 1: Setting absolute max range to 50000
Using new style simulated laser for lms1xx 1
sim lms1xx 1::setConnectionTimeoutSeconds: Setting timeout to 8 secs
You may press escape to exit
sim lms1xx 1: Connected to simulated laser.
Robot does not indicate that it has a gripper.
ArACTS 1 2: Could not connect to ACTS running on localhost:5001 (Connection refu
sed.)
You can do these actions with these keys:
quit: escape
help: 'h' or 'H' or '?' or '/'
You can switch to other modes with these keys:
                          teleop mode: 't' or 'T'
                                                                                         p3dx-sh-lms1xx: Client connected from ubuntu (127.0.0.1)
               unquarded teleop mode: 'u' or 'U'
                                                                                         p3dx-sh-lms1xx: Laser on
                          wander mode: 'w' or 'W'
                                                                                         p3dx-sh-lms1xx: Got CLOSE command, closing connection.
                           laser mode: 'l' or 'L'
                                                                                         p3dx-sh-lms1xx: Client disconnected.
                           bumps mode:
                                                                                         p3dx-sh-lms1xx: Port opened. Listening on TCP port 8101... [13]
                           sonar mode:
                                                                                         p3dx-sh-lms1xx: Ready for a client to connect on TCP port 8101.
                        position mode: 'p' or
                                                                                         p3dx-sh-lms1xx: Client connected from ubuntu (127.0.0.1)
                          camera mode: 'c' or 'C'
                                                                                         p3dx-sh-lms1xx: Laser on
                        command mode: 'd' or 'D'
            report robot config mode: 'o' or '0'
   detailed status/error flags mode: 'f' or 'F'
                                                                                         Time: 0:0:12:24.400 (avg sim/real time: 0.98) 3 active devices MobileSim 0.9.8 (Stage v2.0.0a-...
```

You can control the robot by entering the keys on terminal window.

Assignment1 Announcement

- Assignment1 is now live on NTU COOL.
 - o Deadline: 2021/10/28 13:00
 - Make sure you followed the requirements before submission.